



 **INSTRUCTIONS**

**75**

Using an electric miter saw, cut the fiberglass tube on the line made in the previous step. The fiberglass tube should measure 2 7/8" in length.



 **OPTIONS**

A hacksaw or jigsaw can be used in place of an electric miter saw.



 **INSTRUCTIONS**

**76**

Drill the 7/64" hole that was marked in step #73. Drill the hole ALL THE WAY through both fiberglass tube walls.



 **OPTIONS**

A hand held drill can be used in place of a drill press. If doing this step by hand, make sure that the drill is perfectly perpendicular to the fiberglass tube so that both 7/64" holes will be in the correct location.

 **WHY?**

The hole for the safety pin is a very small hole that needs to be drilled as accurately as possible. Take your time with this step to make sure the pin is drilled in the correct location.