



## INSTRUCTIONS

Purchase the following parts:

- Double braided polyester rope.
- Two steel threaded connectors.
- Twelve steel hose clamps.



## MATERIALS

50 Feet double braided polyester rope 1/4" diameter 400 pound test.  
Two steel threaded connectors 3/16" diameter 600 pound test.  
Twelve double pinch steel hose clamps 5/16" to 7/16".



## WEB

[www.mcmaster.com](http://www.mcmaster.com) part number 3789T312.  
[www.mcmaster.com](http://www.mcmaster.com) part number 8947T15.  
[www.mcmaster.com](http://www.mcmaster.com) part number 6541K51.



## INSTRUCTIONS

Purchase the following parts:

- Straight jaw pincer.
- Heat shrink tubing 3/4" to 3/8".
- One 60" surplus parachute.



## MATERIALS

Straight jaw installation pincer.  
Heat shrink tubing 3/4" to 3/8" - black.  
60" White surplus parachute.



## OPTIONS

The straight jaw pincers work so well tightening the hose clamps on the shock cord that I felt I needed to include them as a *part*. I'm sure there are tools that could be used as an alternative but I wouldn't want to risk the rocket for a \$22.00 tool.



## WEB

[www.mcmaster.com](http://www.mcmaster.com) part number 6541K67.  
[www.mcmaster.com](http://www.mcmaster.com) part number 7496K19.  
[www.aeroconsystems.com](http://www.aeroconsystems.com) part number P60WHITE.